User's Manual

Carbon Dioxide Detector

Model: AT-VLC-ND-A2-RS


Specifications



General Data						
Power supply	24VAC/VDC±10%					
Consumption	3.5 W max. ; 2.0 W avg.					
Analog outputs	Two 0~10VDC/4~20mA for CO2/Temperature measurements PID control output is selectable for CO2					
RS485 interface	Modbus protocol 4800/9600(default)/19200/38400bps; 15KV antistatic protection, independent base address.					
LED light condition selectable	3-color mode (default) Green: ≤1000ppm Orange: 1000~1400ppm Red: >1400ppm Red flashing: CO2 sensor faulty	Working light mode Green on: working Red flashing: CO2 sensor faulty				
Operation condition	0~50℃; 0~95%RH, non condensing					
Storage condition	-10~60℃ / 0~80%RH					
Net Weight / Dimensions	190g /117mm(L)×95mm(W)×36mm(H)					
Installation	wall mounting with 65mm×65mm or 2"×4"wire box					
Housing and IP class	PC/ABS fireproof plastic material, protection class: IP30					
Standard	EMC approval					
Carbon Dioxide						
Sensing element	Non-Dispersive Infrared Detector (NDIR)					
CO ₂ measuring range	0~2000ppm (default)					
CO₂ Accuracy @22℃(72 °F)	±60ppm + 3% of reading or ±75ppm (whichever is greater)					
Temperature dependence	0.2% FS per℃					
Stability	<2% of FS over life of sensor (15 year typical)					
Pressure dependence	0.13% of reading per mm Hg					
Calibration	ABC Logic Self Calibration Algorithm					


Response time	<2 minutes for 90% step change typical				
Signal update	Every 2 seconds				
Display resolution	1ppm				
Warm-up time	2 hours (first time) / 2 minutes (normal operation)				
Temperature and RH (option)					
Temperature sensor (selectable)	Digital integrated temperature and humidity sensor or NTC thermistor				
Measuring range	-20~60°C/-4~140F 0~100%RH relative humidity				
Accuracy	Temp.: <±0.5℃@25℃ RH: <±3.0%RH (20%~80%RH)				

Dimension and Mounting




- ◆ Please note the power supply is 24VAC/VDC±10%. Don't install the detector with over the voltage.
- First of all, please prepare a flat head screwdriver and gently put it deep inside of the hole on the bottom of the detector housing. Then slant the screwdriver and open the cover gently. Do not mount it near diffuser or any steam source, in direct sunlight.
- Mount the wall plate. Place the detector against the wall at desired location; make sure wires can be passed through the notch on the wall plate.
- Connect wires to terminal strips. Make sure wiring connection correct and secure.
- Finally close the cover gently.

Wiring Diagram



Analog Output Selection

- ◆ The default analog output is 0-10V. If you want to change to 4-20mA output, please follow the below.
- Open the cover, you can see five black blocks of J1 & S1~S4. The J1=OFF corresponding to 0-10V and the J1=ON corresponding to 4-20mA. At the same time, connect 'V' side of S1~S4 corresponding to 0-10V and connect 'A' side of S1~S4 corresponding to 4-20mA. As shown figure 4.



Modbus Register

Mode: RTU (MSB First) Baud Rate: 1-4800 2-9600 5-38400 bps default: 2-9600bps 3-14400 4-19200 Start Bits: 1 Data Bits: 8 Stop Bits: 2 default: 2 1 / Parity: None / Odd / Even default: None Modbus Address: 1~247 default: 1

Register	Мар				
Support	Function:	3	4	6	16

Starting	Data Description	Function	Read/	Length	Format	Valid Response	
Register			Write				
Decimal							
0	CO2 Measurement	4	R	2	Float inverse	0~5000 ppm	
2	Temperature Measurement	4	R	2	Float inverse	0.0~50.0 ℃	
4	Humidity Measurement	4	R	2	Float inverse	0.1~100.0 %RH	
Starting	Data Description	Function	Read/	Length	Format	Selection	Default
Register			Write				
Decimal							
0	Modbus Address	3/6	R/W	1	INT16	1~247	1
1	Modbus rate	3/6	R/W	1	INT16	1-4800bps	2
						2-9600bps	
						3-14400bps	

						4-19200bps	
						5-38400bps	
2	Modbus Stop Bit	3/6	R/W	1	INT16	1-None 1Stop Bit;	2
						2-None 2Stop Bit;	
						3-Odd 1Stop Bit;	
						4-Even 1Stop Bit	
3	CO2 offset	3/6	R/W	1	INT16	-300~300ppm	0
4	Temperature offset	3/16	R/W	2	Float inverse	-5.0~5.0 ℃	0.0
6	Relative Humidity offset	3/16	R/W	2	Float inverse	-10~10 %RH	0.0
8	Logic of Relay Control	3/16	R/W	1	INT16	0- Increase CO2 1- Decrease CO2	1
10	Warm-up Time	3/6	R/W	1	INT16	1~600 Seconds	10
11	CO2 Max. Measurement	3/6	R/W	1	INT16	400~10,000 ppm	2000
12	CO2 PID Control Setpoint	3/6	R/W	1	INT16	400~5,000 ppm	800
13	CO2 Relay Control min. Setpoint	3/6	R/W	1	INT16	400~5,000ppm	780
14	CO2 Relay Control max.	3/6	R/W	1	INT16	400~5,000ppm	820
	Setpoint						
15	LED work mode	3/6	R/W	1	INT16	0- 3 color mode;	0
						1- 2 color mode	
16	Buzzer alarm	3/6	R/W	1	INT16	0- Disable	1
17	Buzzer alarm Setpoint of CO2	3/6	R/W	1	INT16	1- Enable 400~5,000ppm	1400
18	LED switch from green to yellow	3/6	R/W	1	INT16	400~5,000ppm	1000
			-				
19	LED switch from yellow to red	3/6	R/W	1	INT16	400~5,000ppm	1400